§ 133.27

(b) The holder of a rotorcraft external-load certificate may apply for an amendment to add or delete a rotorcraft authorization by submitting to the certificate-holding FAA Flight Standards District Office a new list of rotorcraft, by registration number, with the classes of rotorcraft-load combinations for which authorization is requested.

[Doc. No. 18434, 43 FR 52206, Nov. 9, 1978, as amended by Amdt. 133–9, 51 FR 40707, Nov. 7, 1986; Amdt. 133–11, 54 FR 39294, Sept. 25, 1989]

§ 133.27 Availability, transfer, and surrender of certificate.

- (a) Each holder of a rotorcraft external-load operator certificate shall keep that certificate and a list of authorized rotorcraft at the home base of operations and shall make it available for inspection by the Administrator upon request.
- (b) Each person conducting a rotorcraft external-load operation shall carry a facsimile of the Rotorcraft External-Load Operator Certificate in each rotorcraft used in the operation.
- (c) If the Administrator suspends or revokes a Rotorcraft External-Load Operator Certificate, the holder of that certificate shall return it to the Administrator. If the certificate holder, for any other reason, discontinues operations under his certificate, and does not resume operations within two years, he shall return the certificate to the FAA Flight Standards District Office having jurisdiction over the area in which his home base of operations is located.

[Doc. No. 1529, 29 FR 603, Jan. 24, 1964, as amended by Amdt. 133–9, 51 FR 40708, Nov. 7, 1986; Amdt. 133–11, 54 FR 39294, Sept. 25, 1989]

Subpart C—Operating Rules and Related Requirements

§133.31 Emergency operations.

- (a) In an emergency involving the safety of persons or property, the certificate holder may deviate from the rules of this part to the extent required to meet that emergency.
- (b) Each person who, under the authority of this section, deviates from a rule of this part shall notify the Administrator within 10 days after the de-

viation. Upon the request of the Administrator, that person shall provide the certificate-holding FAA Flight Standards District Office a complete report of the aircraft operation involved, including a description of the deviation and reasons for it.

[Doc. No. 24550, 51 FR 40708, Nov. 7, 1986, as amended by Amdt. 133–11, 54 FR 39294, Sept. 25, 1989]

§133.33 Operating rules.

- (a) No person may conduct a rotor-craft external-load operation without, or contrary to, the Rotorcraft-Load Combination Flight Manual prescribed in §133.47.
- (b) No person may conduct a rotor-craft external-load operation unless—
- (1) The rotorcraft complies with §133.19; and
- (2) The rotorcraft and rotorcraft-load combination is authorized under the Rotorcraft External-Load Operator Certificate.
- (c) Before a person may operate a rotorcraft with an external-load configuration that differs substantially from any that person has previously carried with that type of rotorcraft (whether or not the rotorcraft-load combination is of the same class), that person must conduct, in a manner that will not endanger persons or property on the surface, such of the following flight-operational checks as the Administrator determines are appropriate to the rotorcraft-load combination:
- (1) A determination that the weight of the rotorcraft-load combination and the location of its center of gravity are within approved limits, that the external load is securely fastened, and that the external load does not interfere with devices provided for its emergency release.
- (2) Make an initial liftoff and verify that controllability is satisfactory.
- (3) While hovering, verify that directional control is adequate.
- (4) Accelerate into forward flight to verify that no attitude (whether of the rotorcraft or of the external load) is encountered in which the rotorcraft is uncontrollable or which is otherwise hazardous.
- (5) In forward flight, check for hazardous oscillations of the external load, but if the external load is not